

## ***FIELD PAINTING RECOMMENDATIONS***

### **You will need the following materials to complete the installation:**

The following recommendations are suggested from past experience. The company supplying the field coating products should be the priority. Water borne coatings, oil based or enamel coatings, acrylic and epoxy coatings are acceptable for use on the fiberglass doors and frames. Use the coating most appropriate for your environment.

- 120 grit sandpaper.
  - Mineral Spirits or paint manufacturers recommendation.
  - Cleaning Cloth.
1. Lightly scuff sand all surfaces that will be painted using 120 grit sandpaper.
  2. Remove any dust and clean the affected area with a cleaner recommended by the paint manufacturer in their prep instructions.
  3. Field painting can now be completed using a spray gun, brush or roller.
  4. Please call the factory 920-231-2000, if you have any questions.

August 27, 2013