

### HOW TO INSTALL THE ALL FRP FRAME

**THE FRAME HAS BEEN SHIPPED AS A KIT.** CORRIM has found that most openings where doors are being replaced are not square. By shipping the frame as a kit, you can correct the problems and have a frame that fits and holds the door properly.

**The (Concealed Anchor) kit contains the following:**

1. Coated Anchor Caps

**You will need the following equipment to install the frame:**

- A. Two people will be needed to handle the unit.
- B. A long carpenter's level and right angle.
- C. A pencil.
- D. An electric drill.
- E. A flat head and a Phillips screwdriver.
- F. A tape measure.
- G. A supply of shimming material.
- H. An 11/64" drill bit.
- I. Suitable drill bit to go through frame into wall to which frame is being anchored.
- J. A supply of silicone caulking.
- K. Diamond coated step drill, supplied by Corrim. **STEP DRILL TO BE RETURNED TO CORRIM OR AN INVOICE WILL BE SENT FOR THE VALUE OF THE BIT PLUS THE SHIPPING COST.**

#### **OUTLINE OF STEPS TO INSTALL THE CONCEALED ANCHOR**

1. Remove the frame from the opening.
2. Mark the desired location of each anchor on the stop of the hinge leg.
3. Repeat for the strike leg.
4. Drill a 1/2" dia hole thru the frame at the mark locations.
5. Using the 1" dia hole saw drill through the **stop only** for each anchor location.
6. Stand the assembled frame in the rough opening. Shim the frame in the opening where necessary to ensure the frame is square, plumb, parallel and free of twist.
7. Making sure the frame is level, plumb and not twisted secure the center of each frame leg to the wall with the supplied fastener. After re-checking frame for level and plumb fasten the remaining anchors locations.

# **CORRIM Company**

## **FRAME INSTALLATION (Field Prep Concealed Anchor)**

**Page 2 of 2**

8. Install the coated Anchor Caps at the anchor locations. Use a small amount of sealant to seal the cap to the frame.

WE AGAIN REMIND YOU THAT THE MOST IMPORTANT PART OF HAVING THE DOOR WORK PROPERLY IS SEEING THAT THE FRAME IS PROPERLY INSTALLED. IF THERE ARE PROBLEMS, THE MOST LIKELY PLACE THAT PROBLEMS ARE STARTING IS AT THE POINT WHERE THE FRAME AND THE OPENING MEET.

IF YOU HAVE ANY PROBLEMS WITH THE FRAMES, PLEASE REMEMBER THAT CORRIM IS MOST WILLING TO HELP IN ANY WAY. IF YOU HAVE A PROBLEM, CALL US AT (920) 231-2000.

December 5, 2013