

# FRP FRAME SYSTEMS INSTALLATION INSTRUCTIONS

Most CORRIM Company fiberglass frame systems, particularly the standard 5-3/4"x2" profile, are installed by following the long established practices in the door industry.

"T"-Straps, wire straps, expansion anchors, thru-bolts, pipe anchors, floor clips, to mention a few, are all compatible with the 5-3/4"x2" frame. Information on selection of corrosion resistant accessories are available. Installation instructions are included with every frame.

Special profile frames are offered with a selection of anchoring systems. Instructions are included with every frame.

Where special or unusual wall conditions prevail, the factory welcomes a pre-engineering exchange to establish and define a suitable design and installation procedure.

Full installation instructions are listed on our website, [www.corrим.com](http://www.corrим.com).

## CARE & MAINTENANCE OF CORRIM FIBERGLASS DOORS

CORRIM Company fiberglass doors have a gelcoat or polyurethane finish. Should the door become dirty, stained or damaged, first, try cleaning with a diluted solution of mild soap water. For tougher problems, contact the factory.

Under no circumstances, attempt to coat or paint doors or frames without first consulting the factory.

For damage such as dents, cracks or chips, normal materials and practices similar to those of auto body or fiberglass boat repair are applicable (Bondo). Contact the factory for advice. Touch-up kits are available.

## ADJUSTMENT TO FRP DOOR BOTTOM

Cut up to 1-1/4" off the bottom. This leaves a U-shaped channel, all FRP tube, and does not endanger or expose the core. On the bottom it can be left this way if no sterile or sanitizing requirements exist.

To cap the cut, fill with a resin "putty", such as automobile bondo, and smooth off. Apply a strip of 1/8" FRP sheet, clamp and allow filling to set up. Then run some 2" stainless countersunk flathead screws in - about every 8". Sand and either leave as is, or touch up edges with gel coat tinted to match door. (Consult factory.)

Factory can provide the resin filler and touch-up kit, but time must be allowed for shipping by UPS ground or motor freight, as DOT regulations do not permit air shipment of resins or catalyst.

Always be safety minded and protect your eyes. Read all caution notes and warnings.