

CORRIM Company

Corrosion Immune Fiberglass Doors and Frames
1870 Stillman Drive Oshkosh, WI 54901-1414

Phone (920) 231-2000

www.corrim.com

FIELD PAINTING RECOMMENDATIONS

You will need the following materials to complete the installation:

- 120 grit sandpaper
 - Acetone
 - Cleaning Cloth
1. Scuff sand all surfaces that will be painted using 120 grit sandpaper.
 2. Remove any dust and clean the affected area with a damp rag using acetone.
 3. Field painting can now be completed using a spray gun, roller or brush.
 4. Use a quality oil, alkyd, polyurethane or epoxy coating.
 5. Please call the factory 920-231-2000, if you have any questions.

August 27, 2013